JETE

WARRANTY CARD and USER MANUAL

TWS TX5

e-Usermanual

IMPORTIR

PT. DORAN SUKSES INDONESIA

Jl. Lebak Jaya 2 Tengah No. 2, Surabaya

CUSTOMER SERVICE

081217393609

jete.id jeteindonesia

jeteindonesia jeteindonesia

JETE

USER MANUAL

TWS TX5



Please read the instructions carefully
before using the product.

Product Introduction :

Thank you for purchasing JETE products. For optimal and safe performance, it is expected to read the instructions carefully before using this product.

Content Package :

Charging Case



Earbud *2

Stiker

Charging Cable

User Manual

2 Pairs Earcups Size L & S *1
Pair of Installed Earcups in Size M

Description Structure Product :



1. Indicator Light Earbud
2. MFB (Multifunction Button)
3. LED Display Charging Case
4. Charging Port
5. Power Button

Tips : Gently insert the earbuds into your ears and adjust the position to fit your ears.

Attention:
Please open the plastic seals on both ends of the earbuds and do not forget the earbuds in the charger into the charging case for approximately 10 minutes for optimal use.

How to Connect Device with Earbuds :

1. Take the earbuds out of the charging case.
2. Turn on Bluetooth on your device.
3. Then, enable the search function and select "JETE-TX5."
4. The earbuds are ready to use.
5. If you do not pair the earbuds with your device's Bluetooth within 180 seconds after they are active, the earbuds must be restarted.

Note :

- The earbuds will automatically connect to the previously connected device when turned on.
- The connection will be lost when you move out of range and will automatically reconnect when you return to range within 3 minutes.

How to Use :

How to Answer/Reject an Incoming Call Using the Earbuds :

- Press either the right or left earbud once to answer a call.
- Press and hold either the right or left earbud for 2 seconds to reject a call.

Using the Charging Case :

Press the " " icon to answer an incoming call.
Press the " " icon to reject an incoming call.



Tip : Some devices can only answer calls through the device itself. Please adjust according to your device's instructions.

How to End a Call Using the Earbuds :

Press either the right or left earbud once to end a call.

Using the Charging Case :

- Press the " " icon to end a call.
- Press the " " icon to mute the call.



How to Play Music Using the Earbuds :

- Press the left/right earbud once to play/pause a song.
- Next song: Press the right earbud 3 times to play the next song.
- Previous song: Press the left earbud 3 times to play the previous song.

Using the Charging Case :

- Press the " " icon to play/pause a song.
- Press the " " icon to play the previous song.
- Press the " "icon to play the next song.



How to Increase & Decrease Volume Using the Earbuds :

- Press and hold the right earbud for 2 seconds to decrease the volume.
- Press and hold the left earbud for 2 seconds to increase the volume.

Using the Charging Case :

- Press the "-" icon to decrease the volume.
- Press the "+" icon to increase the volume.

How to Activate the Voice Assistant Feature Using the Earbuds :

Press the left earbud 2 times to activate the voice assistant.

How to Change Modes Using the Earbuds :

Press the right earbud 2 times to change modes (Gaming Mode, Music Mode).

Using the Charging Case :

- Press the " " icon to enter Normal Mode.
- Press the " " icon to enter ANC Mode.
- Press the " " icon to enter Transparency Mode.



How to Use Mono Mode on the TX5 Earbuds :

- Take one earbud out of the charging case, and it will connect to the previously paired device.
- Then, play music (this mode can also be used for making phone calls).
- It is recommended that both earbuds function normally; only use this function when needed.

How to Reset to Factory Settings Using the Earbuds:

Take the earbuds out of the charging case, then press either the left or right earbud 6 times until the indicator light turns white and then off. This indicates that the earbuds have been successfully reset.

Using the Charging Case :

- Press the power button 2 times.
- Then press the " " icon to reset to factory settings.



How to Charge :

- Charging Case
  The charging case's LED display will show the percentage number while charging.

Charging Case :

Equalizer

- Press the "◀▶" icon to select the desired equalizer mode.



Screen Lock

Press the "◀▶" icon to select a picture to be set as the Screen Lock.



Light Level

- Press the " ☼ " icon to increase brightness.
- Press the " ☼ " icon to decrease brightness.

Setting Time

Press the " set up " icon to set the hour, date and year.



Camera

- Open the camera app on your smartphone.
- Press the " 📷 " icon to take a picture.



Flash Light

Press the " 🔦 " icon to turn on the Flashlight.



Like

- Press the " ♡ " icon to like content on social media.
- Press the "◀▶" icon to swipe through content on social media.



Countdown / Timer

- Press the " ◀▶ " icon to choose how long you want the countdown to be.
- Press the " set up " icon to start the countdown.



Language Switch

Press the " ◀▶ " icon to select the language to use.



Find My Earphone

- Press the "L" icon to find the Left Earbud.
- Press the "R" icon to find the Right Earbud.
- Press "Start" to begin the search with a sound or ring from the earbud.





How to Use the Application :

1 2

Download on the App Store
versi 2.0.3

Android app on Google Play
versi 3.7.7

4



1. Go to the Play Store / App Store; you can also scan the QR code on the packaging.
2. Download and install the app.
3. Open the app to pair it with the device.
4. Select the "Link Management" menu.



5. Then, a screen will appear that is the same as the image.
   Please wait until the device is detected during the search process.
6. Select “Confirm."
7. If the connection is perfect, a notification will appear like in the image.



A. Simultaneous Interpretation

This feature allows for live voice translation during a conversation.



1. Connect the earbuds to your smartphone.
2. Open the app.
3. Select the "Simultaneous Interpretation" menu.
4. Determine the source and target languages (e.g., English → Indonesian).
5. Choose the output device for each respective language: Earbud or Phone.
6. Begin speaking or listening to your conversation partner.
7. The app will automatically translate and play the translated results through the earbuds and display them on the screen.

B. Phone + Headset Mode

This mode splits the roles between the earbud and the phone. One person speaks through the earbud while the other uses the phone's microphone.



1. Connect the earbuds to your smartphone.
2. Open the app.
3. Select the "Earbuds + Phone" menu.
4. Determine the language used for the earbud and the phone.
5. Give an earbud to your conversation partner.
6. Press the "Earbud/Phone" icon to start the conversation.
7. The app will automatically translate the two-way conversation.

C. Dual Ear Mode



Each earbud is worn by one of two people, used for two-way conversation with automatic translation.

1. Connect the earbuds to your smartphone.
2. Open the app.
3. Select the "Dual Ear Mode" menu.
4. Choose the language for the left and right earbuds as needed.
5. Give one earbud to your conversation partner.
6. The app will automatically detect and translate the voice from each side alternately.

D. Scene Recording



This feature is used to record meeting audio, then convert it into text (transcription), which can also be automatically summarized.

1. Connect the earbuds to your smartphone.
2. Open the app.
3. Select the "Scene Recording" menu.
4. Determine the language used in the meeting.
5. Press the Record button when the meeting starts.
6. When finished, select Transcribe to convert the recording into text, or select Summary to create a summary.
7. If you choose a summary, select an available template.

8. Press Summarize with this template to continue.
9. The transcription or summary results can be saved or shared as needed.

E. Audio and Video Calls





This feature is used for audio/video calls with live translation within the app, allowing two people to communicate smoothly in different languages during the call.

1. Connect the earbuds to your smartphone.
2. Open the app.
3. Select the "Audio and video calls" menu.
4. Choose the call method (Video Call/Voice Call).
5. Determine the language used by your conversation partner and your own.
6. Enter your conversation partner's ID code.
7. Select a location.
8. Select Invite.

F. AI Wallpaper

This feature creates and sets wallpapers generated by artificial intelligence (AI).

1. Enter the desired command.
2. Select "Start Creating".
3. Wait a moment until the image appears.
4. Select "Save" to save it or "Regenerate" to create a new one.
5. Choose the image that you have created in the "Gallery".



Specifications :

Bluetooth Version	: V5.4
Earbud Battery	: 40mAh*2
Charging Case Battery	: 500mAh
Sensitivity	: -38±1dBV
Input	: DC 5V/1A
Impedance	: 32Ω±15%
Wireless Working Range	: 15m (Without Obstacles)
Frequency	: 20Hz-20KHz
Standby Time	: 40 H
Talk Time	: 3 H
Charging Time	: 2 H (Charging Case) 1.5 H (Earbud)
Weight	: 45.6g (Charging Case) 4g*2 (Earbud)